

INSTRUCTION PAPER


ALEXA | Bistro table 108/92/74h - TEAK TOP

DIPHANO


OUTDOOR FURNITURE

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).

CONTENT




STEP 1: CONNECT TABLE TOP



Connect the pole (H) to the table top (I) by fixating the bolt (A) with the washer (B) in the correct order. Repeat this 3 times so you have a bolt at every corner of the pole.

STEP 2: CONNECT BASE



Connect the base (G) to the other side of the pole (H) by fixating the bolt (D) with the washer (E) in the correct order. Repeat this action 2 times.


INSTRUCTION PAPER

ALEXA | Bistro table 108/92/74h - TEAK TOP

DIPHANO


OUTDOOR FURNITURE

STEP 3: TURN TABLE



Turn the table carefully to its normal position with at least 2 persons.

STEP 4: ADJUST FEET



Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.



DINING
ARMCHAIR



FOLDING
DIRECTOR'S
CHAIR



BARSTOOLS
77 | 62h



FOLDING BEACH
CHAIR



LOUNGER



EXTENDABLE TABLES



ROUND DINING TABLE 148xR



BISTRO TABLES
108 | 92 | 74h

www.diphano.com

Diphano cannot be held responsible if the assembly instructions are not followed properly.