

DIPHANO



Icon

dining table 226x104
teak

INSTRUCTION MANUAL


how to assemble dining the table

CONTENT

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).



A
1x table top



B
4x leg



C
4x bolt (M8x15mm)



D
8x bolt (M8x20mm)



E
8x washer (8mm)




F
1x hex key

Diphano cannot be held responsible if the assembly instructions are not followed properly.

1

CONNECT THE LEGS (1/2)


Connect the legs (B) to the table top (A) by fixing the bolts (D) with the washers (E) in the correct order. Repeat this action for each leg.



2

CONNECT THE LEGS (1/2)


Fixate by screwing the bolt (C) into the pre-made hole.
Repeat this action for each leg.



3

TURN TABLE


Turn the table carefully to its normal position with at least 4 persons.



4

ADJUST FEET

Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.



maintenance & care

POWDERCOATED ALUMINIUM

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth.

NATURAL TEAK

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth. If the teak is 100% dry and free of dust, you can apply our Teak stain protector to make it repellent to water and moisture. Avoid the use of abrasive products and solvents and high pressure cleaning.



Teak stain protector

Saturates teak to make it repellent to water and moisture. Helps to prevent stains (e.g. wine stains, barbecue stains...). Easy to apply. Transparent finishing.

DIPHANO

OUTDOOR FURNITURE

www.diphano.com

Textielstraat 4 - 8790 Waregem - Belgium
Tel. +32 (0)56 980 008 - info@diphano.com