

INSTRUCTION PAPER


Natural | Dining table 300x113

DIPHANO


OUTDOOR FURNITURE

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).


CONTENT




1x table top




4x leg




8x bolt M8




8x washer



1x hex key




2x wooden cable tensioner




1x flat wrench

STEP 1: PLACE THE TABLE TOP UPSIDE DOWN



Position the table top (A) upside down on the ground. Make sure to cover the ground to prevent any damage or scratching. You can use the cardboard box for this.

STEP 2: FIXATE LEGS



Position the leg (B) onto the table top (A). Now use the hex key (E) to fixate the leg by screwing the 2 bolts (C) with the washer (D) into the pre-made holes. Repeat this action for the other 3 legs.


INSTRUCTION PAPER

Natural | Dining table 300x113

DIPHANO

OUTDOOR FURNITURE

STEP 3: PLACE CABLE TENSIONERS



Place the wooden cable tensioner (F) underneath the cable in the middle of the table top. Use the flat wrench (G) to tighten the cables at the 2 ends of the cable. Repeat this action for the other side. Now turn the table to its normal position.

ATTENTION



DO NOT PRESSURE CLEAN!



DO NOT SIT ON THE TABLE!



RECTANGULAR
DINING TABLES



SQUARE
DINING TABLES



RECTANGULAR
COFFEE TABLES S



SQUARE
COFFEE TABLES S



RECTANGULAR
LOUNGE TABLES Z



SQUARE
LOUNGE TABLES Z

www.diphano.com

Diphano cannot be held responsible if the assembly instructions are not followed properly.