

basic & Sunbrella® 100% Solution dyed acrylic

## Washing & cleaning instructions



- (E) machine wash at 30° - do not bleach - do not dry clean - do not iron - do not tumble dry
- (N) machinewasbaar op 30° graden - bleken niet toegestaan - niet droog reinigen - niet strijken - niet drogen in droogtrommel
- (F) lavable en machine à 30° - eau de javel interdite - nettoyage à sec interdit - repassage exclu - séchage en tambour interdit
- (D) maschinenwäsche bei 30°, feinwäsche - bleichen nicht erlaubt - nicht chemisch reinigen - nicht bügeln - nicht trommeltrocknen
- (ES) lavado a máquina a 30° - no usar blanqueador de cualquier - no lave en seco - no planchar - no usar secadora
- (I) lavare a macchina massimo 30° - no candeggio - non lavare a secco - no stirare - no a tamburo

### ALL WEATHER BASIC + ALL WEATHER SUNBRELLA®

The all weather cushions can stay outside from spring till autumn. The all weather filling dries three times as fast as a normal filling and cannot rot. The drying time depends on the weather conditions. After heavy rain we advise to put the cushions upright so that the water can escape from the cushions. This will considerably shorten the drying time as will placing the cushion in the sunshine or in the wind.

### MACHINE WASH

- Wash the sofa covers inside out with the zipper closed;
- When the sofa cover uses Velcro, apply a protective cloth or strip;
- Use neutral detergents only;
- Wash at 30°C using gentle cycle;
- Use minimal centrifugation;
- Do not use softener;
- Do not wash with other textiles or garments;
- Do not load the washing machine excessively;
- With the cover still moist stretch in both directions;
- Let the fabric air-dry;
- Do not iron.

### STAIN REMOVAL

- Treat stains as soon as they occur;
- Brush off loose dirt;
- Wipe the stain with a sponge or cotton using water or a mild soap-water blend (no detergent);
- Allow soap to soak in (2 to 3 minutes);
- Rinse thoroughly;
- Air dry.

### STORAGE

- (E) Please put the cushions in a dry, dark and well-aired space when they are not being used. Never put moist cushions in a cushion box.
- (N) De kussens op een droge, donkere en goed verluchte ruimte bewaren wanneer ze niet gebruikt worden. Stop de kussens nooit vochtig in een kussenbox.
- (F) Quand vous n'utilisez pas les coussins, il est conseillé de les entreposer dans un endroit sec, sombre et bien aéré.
- (D) Bitte lagern Sie die Kissen bei Nichtnutzung nur an trockenen, dunklen und gut durchlüfteten Plätzen. Lagern Sie keine feuchten Kissen in der Kissenbox.
- (ES) Guarde los cojines que no utilice en un lugar seco, oscuro y con buena ventilación. No guarde nunca cojines húmedos en un arcón o baúl
- (I) Nei periodi in cui non sono utilizzati, si consiglia di conservare i cuscini al buio, in un luogo asciutto e ben aerato. Non lasciare mai i cuscini umidi nell'apposita cassa portacuscini.