
INSTRUCTION PAPER






DUTDOOR FURN**i**ture

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).




STEP 1: ASSEMBLE LEGS



Slide the outer legs (M) equally onto the table top (L). Fixate the legs by screwing the bolts (A,E) with the washer (B,F)and spring washer (C,G) using the hex keys (D,H). Make sure you follow the correct order as indicated by the letters in the picture. Repeat this action for the other side.

STEP 2: TURN TABLE




Turn the table carefully to its normal position with at least 2 persons.

INSTRUCTION PAPER

SELECTA | Dining table 160x80




STEP 3: PLACE BUMPERS




Place the bumpers (I) with the washers (J,K) on the correct positions as shown on the topview on the right. Check during setup which washer is neccessary for adjusting the glass top on the frame, the 1mm or the 2mm.

STEP 4: PLACE TABLE TOP



Carefully place the table top (N) in the lower part of the support with at least 2 persons.

STEP 5: ADJUST FEET



Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.

