


INSTRUCTION PAPER

SELECTA | Extendable table 225-345x108


DIPHANO
OUTDOOR FURNITURE

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).

CONTENT




STEP 1: PLACE SILICONE CAPS




Place 4 silicone caps (E) onto the right side of the table top (F) as shown in the picture. Repeat this for the left side.

STEP 2: SLIDE LEGS ON TABLE TOP



Slide the legs (G) equally into the table top (F).

STEP 3: FIXATE LEGS



Fixate the legs (G) with the table top (F) by following the 3 steps. Make sure you follow the correct order as indicated by the letters in the picture. Repeat this for the other 3 corners.


INSTRUCTION PAPER

SELECTA | Extendable table 225-345x108

DIPHANO


OUTDOOR FURNITURE

STEP 4: TURN TABLE




Turn the table carefully to its normal position with at least 6 persons.

STEP 5: OPEN TABLE




Slide the 2 table tops outwards (1), tilt the middle table top in the direction indicated by the arrows (2). Slide the 2 outer table tops back inwards (3).

STEP 6: PLACE REMAINING BOLTS



Fixate 4 bolts (B) with the washers (C) in the remaining center holes at the left side and repeat this for the remaining center holes at the right side. Make sure you follow the correct order as indicated by the letters in the picture.

STEP 7: ADJUST FEET



Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.



DINING
ARMCHAIR



LOUNGE CHAIR



FOOTREST



BEACH CHAIR



DECK CHAIR



LOUNGERS



DINING TABLES



HIGH DINING TABLES



EXTENDABLE TABLE



BISTRO TABLES
108 | 92 | 74h

www.diphano.com

Diphano cannot be held responsible if the assembly instructions are not followed properly.