

INSTRUCTION PAPER


ALEXA | Barstool 77h - 62h

DIPHANO


OUTDOOR FURNITURE

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).


CONTENT




2x bolt (M6x28mm)



2x bolt (M6x15mm)




1x hex key (5)




1x alu intermediate piece

CONNECT INTERMEDIATE PIECE



RESULT



Place the intermediate piece (D) with the long side to the front and the short side at the back as shown in the picture. Now use the hex key (C) to fixate the intermediate piece with the barstool by screwing the 15mm bolts (B) at the front and the 28mm bolts (A) at the back.



DINING
ARMCHAIR



FOLDING
DIRECTOR'S
CHAIR



BARSTOOLS
77 | 62h



FOLDING BEACH
CHAIR



LOUNGER



EXTENDABLE TABLES



ROUND DINING TABLE 148xR



BISTRO TABLES
108 | 92 | 74h

www.diphano.com

Diphano cannot be held responsible if the assembly instructions are not followed properly.