

INSTRUCTION PAPER


ALEXA | Round dining table 148xR

DIPHANO


OUTDOOR FURNITURE

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).

CONTENT




1x base




1x pole


COMPONENTS TO FIXATE BASE:




1x hex key 5mm



4x bolt M8x25mm




4x spring washer M8




4x washer M8


COMPONENTS TO FIXATE TABLE TOP/ALU SUPPORT:




1x hex key 4mm



4x bolt M6x20mm




4x spring washer M6



4x washer M6


ASSEMBLY INSTRUCTIONS BASE + POLE

STEP 1: CONNECT THE POLE TO THE BASE



Use the hex key (C) to assemble the aluminium pole (B) onto the base (A) as shown in the picture. Make sure you follow the correct order as indicated by the letters in the picture.


STEP 2: TURN THE BASE + POLE



Turn the base with the pole carefully to its normal position with at least 2 persons.


ASSEMBLY INSTRUCTIONS **TEAK** TABLE TOP

EXTRA COMPONENTS FOR **TEAK** TABLE TOP:




1x teak table top

STEP 1: SECURE TABLE TOP



Carefully place the table top (K) onto the pole (B) so the pre-made holes match. Now use the hex key (G) to fixate the table top (K) onto the pole (B). Make sure you follow the correct order as indicated by the letters in the picture.


STEP 2: ADJUST FEET




Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.

ASSEMBLY INSTRUCTIONS CERAMIC TABLE TOP


EXTRA COMPONENTS FOR **CERAMIC** TABLE TOP:




1x alu support



1x ceramic top




13x bumper Ø13 M5




13x plastic washer M5

STEP 1: SECURE ALU SUPPORT




Carefully place the alu support (M) onto the pole (B) so the pre-made holes match. Now use the hex key (G) to fixate the alu support (M) onto the pole (B). Make sure you follow the correct order as indicated by the letters in the picture.

STEP 2: PLACE BUMPERS (AND WASHERS)




Place the bumpers (O) on the correct positions as shown in the picture. Check during setup if your ceramic table top (N) is placed stable onto the alu support (M). If not, you can add plastic washers (P) on the necessary positions.

STEP 3: PLACE CERAMIC TABLE TOP



Carefully place the ceramic table top (N) onto the alu support with minimal 4 persons.


STEP 5: ADJUST FEET



Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.


ASSEMBLY INSTRUCTIONS TRESPA® TABLE TOP

EXTRA COMPONENTS FOR TRESPA® TABLE TOP:




1x Trespa® top

STEP 1: SECURE TABLE TOP



Carefully place the table top (L) onto the pole (B) so the pre-made holes match. Now use the hex key (G) to fixate the table top (L) onto the pole (B). Make sure you follow the correct order as indicated by the letters in the picture.

STEP 2: ADJUST FEET



Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.



DINING
ARMCHAIR



FOLDING
DIRECTOR'S
CHAIR



BARSTOOLS
77 | 62h



FOLDING BEACH
CHAIR



LOUNGER



EXTENDABLE TABLES



ROUND DINING TABLE 148xR



BISTRO TABLES
108 | 92 | 74h