

DIPHANO



Landscape Teak

INSTRUCTION MANUAL

how to connect the modules

CONTENT

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).



A
2x clip system



B
2x screw



C
2x washer




E
1x hex key

Diphano cannot be held responsible if the assembly instructions are not followed properly.

1

UNSCREW CLIP SYSTEMS

Use the hex key (D) to unscrew the clip systems which you can find on the bottom of the module.




2

ATTACH TO FIRST MODULE

Attach one side of the aluminium clip system onto the hole on the side of the module (see image). Repeat the same action for the second clip system.


Caution: Do not yet fix the screws too tight.



3

PLACE SECOND MODULE


Place the second module next to the first one.



4


ATTACH MODULES

Attach the other side of both aluminium clip systems onto the second module.
Then tighten all screws.






how to adjust the feet

Check with a spirit level if the modules are placed level. If not, (un)screw the adjustable feet until your concept is completely level. This ensures each module can be leveled so it fits perfectly to the next module.



how to fixate the seat cushion

Each module is standard equipped with velcro strips (secured strips can easily be unfastened if necessary). Place the seat cushion on the module so the velcro parts on the seat cushion matches the velcro parts on the module.



maintenance & care

POWDERCOATED ALUMINIUM

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth.

NATURAL TEAK

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth. If the teak is 100% dry and free of dust, you can apply our Teak stain protector to make it repellent to water and moisture. Avoid the use of abrasive products and solvents and high pressure cleaning.



Teak stain protector

Saturates teak to make it repellent to water and moisture. Helps to prevent stains (e.g. wine stains, barbecue stains...). Easy to apply. Transparent finishing.

FABRICS

Simply brush away loose dirt. Spray on a cleaning solution of water and mild soap. Use a soft bristle brush to clean and allow cleaning solution to soak into the fabric. Rinse thoroughly until all soap residue is removed and allow to air-dry.



DIPHANO

OUTDOOR FURNITURE

www.diphano.com

Textielstraat 4 - 8790 Waregem - Belgium
Tel. +32 (0)56 980 008 - info@diphano.com