

# INSTRUCTION PAPER

LINK | Base 240 - 120

DIPHANO

OUTDOOR FURNITURE

## CONTENT



4x teak leg with adjustable feet




12x bolt (3 bolts/leg)




1x hex key



2x protection profiles/base



topplate base 120



topplate base 240


## ASSEMBLY INSTRUCTIONS



❶ Unpack the base carefully. Make sure you have enough space during assembly. Use the carton box to prevent damaging/scratching during assembly.



❷ Start by installing the feet: place the 'topplate base' upside down and fixate the teak legs with the 3 supplied screws. Repeat for each teak leg.





❸ Turn the module with at least 2 persons.

# INSTRUCTION PAPER


LINK | Base 240 - 120

# DIPHANO


OUTDOOR FURNITURE



**4** To connect 2 or more bases we advise to use the supplied rubber profiles: apply them as you can see on the instructions ( $\pm 8\text{cm}$  from the outside). **IMPORTANT:** to prevent damaging of the bases while placing several modules together.



**5** Place the bases in the desired concept.



**6** You can level the modules by (un)screwing the adjustable teak feet.



CORNER SEATS 240 | 120 L/R



MIDDLE SEATS 240 | 120



END SEATS 240 | 120 L/R



SOFA 2,5-SEATER 240



LOUNGERS 120



FOOTSTOOLS 240 | 120



COFFEE TABLES 240 | 120



DINING TABLE 240x92



ROUND  
DINING TABLE 148xR



ROUND  
BISTRO TABLE 80xR



EASY PROTECTIVE COVER FOR CONCEPT (EPCC)  
AVAILABLE FOR EACH CONCEPT



EASY PROTECTIVE COVER (EPC)  
AVAILABLE FOR EACH MODULE

[www.diphano.com](http://www.diphano.com)

Diphano cannot be held responsible if the assembly instructions are not followed properly.