

DIPHANO



Switch Fabric

COLLECTION SHEET



The Switch Fabric lights up your outdoor space. The satin white frame makes this robust collection sparkle with lightness and elegance. Thick, soft cushions invite you to plunge in them and relax. The soft fabric is weatherproof and detachable for easy maintenance.








collection overview

lounge chair



2,5-seater



loungers



double lounger



coffee table S




technical information

MATERIALS & COLOURS


 frame: pca | finishing: fabric | cushion set: fabric (FDF)





 frame: pca | fabric: textylene | cushion set: fabric (FDF)



 frame: pca | table top: teak slats (18mm/0.71")



 frame: pca | table top: ceramic (12mm/0.47")



OPTIONS



protective
cover



stackable
seaters



stackable
lounger



velcro fixation




waterproof



easy
maintenance

FEATURES

FOAM TYPE



type 7
fabric + interliner
+ indoor foam



maintenance

POWDERCOATED ALUMINIUM

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth.

FABRICS

Simply brush away loose dirt. Spray on a cleaning solution of water and mild soap. Use a soft bristle brush to clean and allow cleaning solution to soak into the fabric. Rinse thoroughly until all soap residue is removed and allow to air-dry.



NATURAL TEAK

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth. If the teak is 100% dry and free of dust, you can apply our Teak stain protector to make it repellent to water and moisture. Avoid the use of abrasive products and solvents and high pressure cleaning.



Teak stain protector

Saturates teak to make it repellent to water and moisture. Helps to prevent stains (e.g. wine stains, barbecue stains...). Easy to apply. Transparent finishing.

CERAMIC

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution or Ceramic cleaner. Rinse thoroughly and pat dry with a cloth.



Glass, ceramic, Trespa® cleaner & polisher

Makes hard surfaces repellent to water, moisture and dirt. Cleans and removes stains without scratching using the included cloth.

DIPHANO

OUTDOOR FURNITURE

www.diphano.com

Textielstraat 4 - 8790 Waregem - Belgium
Tel. +32 (0)56 980 008 - info@diphano.com