DIPHANO




Selecta dining table 80x80

assembly instructions


CONTENT

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).



ASSEMBLE OUTER LEGS


Use the hex key (D) to screw the the aluminium legs onto the table top (L) as shown in the picture. Make sure you follow the correct order as indicated by the letters in the picture. Repeat this action for the other side.



TURN TABLE


Turn the table carefully to its normal position with at least 4 persons.






PLACE BUMPERS


Place the bumpers (I) with the washers (J,K) on the correct positions as shown on the topview. Check during setup which washer is neccessary for adjusting the ceramic top on the frame, the 1mm or the 2mm.






PLACE TABLE TOP

Carefully place the table top (P) in the lower part of the support with at least 4 persons.



ADJUST FEET

Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.



maintenance & care

POWDERCOATED ALUMINIUM

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth.

CERAMIC

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution or Ceramic cleaner. Rinse thoroughly and pat dry with a cloth.



Glass, ceramic, Trespa® cleaner & polisher

Makes hard surfaces repellent to water, moisture and dirt. Cleans and removes stains without scratching using the included cloth.





www.diphano.com