

DIPHANO



Ray

coffee tables

INSTRUCTION MANUAL

This instruction manual applies to the following models:



coffee table (organic) S 100xR (33,5h)



coffee table (organic) S 80xR (35,5h)



coffee table (organic) A 60xR (28,5h)




coffee table (organic) B 42xR (43,5h)


how to assemble ceramic coffee tables

CONTENT


Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).



A
1x frame



B
1x table top



C
3x bolt M5



D
3x leg




E
1x hex key M5

Diphano cannot be held responsible if the assembly instructions are not followed properly.

1

PLACE FRAME


Place the frame (A) onto the back of the table top (B) so the holes in the frame match with the upserts on the table top.



2

FIXATE FRAME


Fixate by screwing the bolts (C) into the upserts with the hex key (E).



3

CONNECT LEGS


Connect the legs (D) to the frame (A) by screwing them into the provided holes.




how to assemble alu coffee tables

CONTENT

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).



A
1x frame



B
1x table top



C
3x bolt M5



D
3x washer M6



E
3x leg




F
1x hex key M5

Diphano cannot be held responsible if the assembly instructions are not followed properly.

1

PLACE FRAME


Place the frame (A) onto the back of the table top (B) so the holes in the frame match with the upserts on the table top.



2

FIXATE FRAME


Fixate by screwing the bolts (C) with the washers (D) into the upserts with the hex key (F).



3

CONNECT LEGS

Connect the legs (E) to the frame (A) by screwing them into the provided holes.



maintenance & care

POWDERCOATED ALUMINIUM

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth.

NATURAL TEAK

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth. If the teak is 100% dry and free of dust, you can apply our Teak stain protector to make it repellent to water and moisture. Avoid the use of abrasive products and solvents and high pressure cleaning.



Teak stain protector

Saturates teak to make it repellent to water and moisture. Helps to prevent stains (e.g. wine stains, barbecue stains...). Easy to apply. Transparent finishing.

CERAMIC

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution or Ceramic cleaner. Rinse thoroughly and pat dry with a cloth.



Glass, ceramic, Trespa® cleaner & polisher

Makes hard surfaces repellent to water, moisture and dirt. Cleans and removes stains without scratching using the included cloth.

DIPHANO

OUTDOOR FURNITURE

www.diphano.com

Textielstraat 4 - 8790 Waregem - Belgium
Tel. +32 (0)56 980 008 - info@diphano.com