

DIPHANO



**Selecta**

dining table 160x80

INSTRUCTION MANUAL

# assembly instructions

## CONTENT

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).



**A**  
8x bolt (M8x40mm)



**B**  
8x washer (M8)



**C**  
8x spring washer (M8)



**D**  
1x hex key (6)



**E**  
4x bolt (M6x15mm)



**F**  
4x washer (M6)



**G**  
4x spring washer (M6)



**H**  
1x hex key (5)



**I**  
18x bumper



**J**  
18x washer (1mm)



**K**  
18x washer (2mm)



**L**  
1x alu table top support




**M**  
2x alu outer leg



**N**  
1x table top


## ASSEMBLE OUTER LEGS

Slide the outer legs (M) equally onto the table top support (L).  
Fixate the legs by screwing the bolts (A,E) with the washer (B,F) and spring washer (C,G) using the hex keys (D,H). Make sure you follow the correct order as indicated by the letters in the picture. Repeat this action for the other side.




## TURN TABLE


Turn the table carefully to its normal position with at least 4 persons.



## PLACE BUMPERS


Place the bumpers (I) with the washers (J,K) on the correct positions as shown on the topview. Check during setup which washer is necessary for adjusting the ceramic top on the frame, the 1mm or the 2mm.






## PLACE TABLE TOP

Carefully place the table top (P) in the lower part of the support with at least 4 persons.



## ADJUST FEET

Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.



# **maintenance & care**

## **POWDERCOATED ALUMINIUM**

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution. Rinse thoroughly and pat dry with a cloth.

## **CERAMIC**

Simply brush away loose dirt, rinse, and clean with a mild, lukewarm soapy solution or Ceramic cleaner. Rinse thoroughly and pat dry with a cloth.



### **Glass, ceramic, Trespa® cleaner & polisher**

Makes hard surfaces repellent to water, moisture and dirt. Cleans and removes stains without scratching using the included cloth.



# DIPHANO

OUTDOOR FURNITURE

[www.diphano.com](http://www.diphano.com)

Textielstraat 4 - 8790 Waregem - Belgium  
Tel. +32 (0)56 980 008 - [info@diphano.com](mailto:info@diphano.com)