INSTRUCTION PAPER

METRIS | Bistro table 108/92/74h

DIPHANO
OUTDOOR FURNITURE

Start by unpacking everything carefully. Make sure to cover the floor to prevent any damage or scratching (you can use the cardboard box for this).

CONTENT

A

4x bolt (M6x20mm)

B

4x washer (M6)

C

1x hex key (4)

D

3x bolt (M8x30mm)

E

3x washer (M8)

F

1x hex key (5)

G

1x base

H

1x pole

I

1x alu table top

STEP 1: CONNECT TABLE TOP

Connect the pole (H) to the table top (I) by fixating the bolt (A) with the washer (B) in the correct order. Repeat this 3 times so you have a bolt at every corner of the pole.

STEP 2: CONNECT BASE

Connect the base (G) to the other side of the pole (H) by fixating the bolt (D) with the washer (E) in the correct order. Repeat this action 2 times.

INSTRUCTION PAPER

METRIS | Bistro table 108/92/74h

DIPHANO
OUTDOOR FURNITURE

STEP 3: TURN TABLE

Turn the table carefully to its normal position with at least 2 persons.

STEP 4: ADJUST FEET

Check with a spirit level if the table is placed level. If not, (un)screw the adjustable feet till your table is completely level.

DINING ARMCHAIR | BARSTOOLS 78 | 62h | LOUNGER | BENCHES & LOW TABLES

SIDE TABLE | BISTRO TABLES 108 | 74h | DINING TABLES 92 | 75h | PARTY TABLES 109 | 92h | BAR & BAR TEAK

www.diphano.com

Diphano cannot be held responsible if the assembly instructions are not followed properly.

PIDE210402